

frequently asked questions

Network Nav Display

“How do I connect the NMEA input and NMEA output wires on my Nav Display?”

Network Nav with a 4-Pin Connector (Cable 610-0A-088) – serial numbers prior to NNAV9603101

Pin Number	Colour	Function
1	Red	NMEA Input +
2	Blue	NMEA Input -
3	Yellow	NMEA Output +
4	Green	NMEA Output -
n/c	Screen	Screen

Network Nav with a 6-Pin Connector (Cable 610-0A-038) – serial numbers from NNAV9603101

Pin Number	Colour	Function
3	Green	NMEA Input +
4	Yellow	NMEA Input -
1	Black	NMEA Output +
5	White	NMEA Output -
6	Screen	Screen
2	Red	Not used, cut-back